

MITSUBISHI

CL2X16-D1MJ1V

CC-Link/LT Remote I/O Module

Thank you very much for purchasing this product.

Please read this manual thoroughly before starting to use the product and handle the product properly.

User's Manual

MODEL	CL2X16-D1MJ1V-U
MODEL Number	13JY39
IB(NA)-0800392-A(0708)/MEE	

© 2007 MITSUBISHI ELECTRIC CORPORATION

●SAFETY PRECAUTIONS●

(Read these precautions before using.)

Please read this manual carefully and pay special attention to safety in order to handle this product properly. Also pay careful attention to safety and handle the module properly. These precautions apply only to Mitsubishi equipment. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions. These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".

	DANGER	Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.
	CAUTION	Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by **CAUTION** may also be linked to serious results. In any case, it is important to follow the directions for usage. Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]

	DANGER
● Configure an interlock circuit in a sequence program so that the system operates on the safety side using the communication status information in the event the data link falls into a communication problem. Otherwise, erroneous output and malfunction may result in accidents.	
● Input could be switched on or off when a problem occurs in the remote I/O modules. So build an external monitoring circuit that will monitor any input signals that could cause a serious accident.	

	CAUTION
● Do not have control cables and communication cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.	

[INSTALLATION PRECAUTIONS]

	CAUTION
● Use the module in an environment that meets the general specifications contained in this manual. Using this module in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.	
● Do not directly touch the module's conductive parts. Doing so could cause malfunction or trouble in the module.	
● Securely fix the module in place using the DIN rail. If the module is not securely fixed, it may fall off or cause malfunction.	

[WIRING PRECAUTIONS]

	DANGER
● Completely turn off the externally supplied power used in the system when installing or placing wiring. Not completely turning off all power could result in electric shock or damage to the product.	

	CAUTION
● Wire the module correctly upon verifying the product's rated voltage and the connector pin arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire and/or product failure.	
● Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.	

[STARTING AND MAINTENANCE PRECAUTIONS]

	DANGER
● Switch off all phases of the externally supplied power used in the system when cleaning the module or retightening the terminal or module mounting screws. Not doing so could result in electric shock.	

	CAUTION
● Do not disassemble or modify the module. Doing so may cause failure, malfunction, injury, or fire.	
● The module case is made of resin; do not drop it or subject it to strong shock. A module damage may result.	
● Completely turn off the externally supplied power used in the system before mounting or removing the module. Not doing so could result in damage to the product.	
● Before touching the module, always touch grounded metal, etc. to discharge static electricity from the human body, etc. Not doing so can cause the module to fail or malfunction.	

[DISPOSAL PRECAUTIONS]

	CAUTION
● When disposing of this product, treat it as industrial waste.	

1. Overview

This user's manual explains specifications and names of individual parts of the CL2X16-D1MJ1V type CC-Link/LT remote I/O module (hereinafter abbreviated as remote I/O module).

2. Specifications

2.1 General Specifications

The general specifications for the remote I/O module are shown in the following table.

Item		Specifications				
Operating ambient temperature		0 to 55℃				
Storage ambient temperature		-25 to 75℃				
Operating ambient humidity		5 to 95%RH, non-condensing				
Storage ambient humidity		5 to 95%RH, non-condensing				
Vibration resistance	Conforming to JIS B 3502, IEC 61131-2		Frequency	Acceleration	Amplitude	10 times each in X, Y, Z directions (for 80 min.)
		Under intermittent vibration	10 to 57Hz	—	0.075mm (0.003in.)	
			57 to 150Hz	9.8m/s ²	—	
		Under continuous vibration	10 to 57Hz	—	0.035mm (0.001in.)	
			57 to 150Hz	4.9m/s ²	—	
Shock resistance		Conforming to JIS B 3502, IEC 61131-2 (147 m/s ² , 3 times in each of 3 directions X, Y, Z)				
Operating ambience		No corrosive gases				
Operating altitude*3		2000m (6562ft.) max.				
Installation location		Inside control panel				
Overvoltage category *1		II max.				
Pollution level *2		2 max.				

*1: This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises. Category II applies to equipment for which electrical power is supplied from fixed facilities. The surge voltage withstand level for up to the rated voltage of 300 V is 2500 V.


*2: This index indicates the degree to which conductive material is generated in terms of the environment in which the equipment is used. Pollution level 2 is when only non-conductive pollution occurs. A temporary conductivity caused by condensing must be expected occasionally.

*3: Do not use or store the PLC under pressure higher than the atmospheric pressure of altitude 0m. Doing so can cause a malfunction. When using the PLC under pressure, please contact your sales representative.

2.2 Performance specifications


The performance specifications for the remote I/O module are shown in the following table.

Type		CL2X16-D1MJ1V		
Item				
Number of inputs		16 points		
Isolation method		Photocoupler isolation		
Rated input voltage		24V DC (Common with the module power supply)		
Rated input current		Approx. 4mA		
Operating voltage range		Common with the module power supply		
Input derating		Refer to the derating chart.		
ON voltage/ON current		19V or higher/3mA or higher		
OFF voltage/OFF current		11V or lower/1.7mA or lower		
Input resistance		5.6kΩ		
Response time	Response time setting		0.5ms (High speed response type)	1.5ms (Standard type)
	OFF → ON	TYP.	0.05ms	—
		MAX.	0.1ms	1.5ms
	ON → OFF	TYP.	0.2ms	—
		MAX.	0.5ms	1.5ms
Common wiring method		16 points/1 common (2 points) (MIL connector 1-wire type)		
Input method		Positive common		
Number of stations occupied		In 4-point mode: Occupies 4 stations, In 8-point mode: Occupies 2 stations, In 16-point mode: Occupies 1 station		
Maximum allowable current for I/O power supply		1.0A or lower/common		
Module power supply	Voltage	20.4 to 28.8V DC (ripple ratio: within 5%)		
	Current consumption	45mA or lower (When 24V DC and all points on)		
	Current on startup	70mA or lower (24V DC)		
Noise durability		DC type noise voltage 500Vp-p, noise width 1μs, noise carrier frequency 25 to 60Hz (noise simulator condition) First transient/noise burst IEC 61000-4-4: 2kV		
Withstand voltage		500V AC for 1 minute between primary (external DC terminal) and secondary (internal circuit)		
Insulation resistance		10MΩ or more between primary (external DC terminal) and secondary (internal circuit) when measured with a 500V DC insulation resistance tester		
Protection class		IP2X		
Weight		0.05kg		
I/O part connection method		20 pin MIL connector		
Module installation method		DIN rail installation, Can be installed in six directions		



3. Part Names

This section explains the names of the components for the remote I/O module.



Connector for I/O interface		Pin No.	Signal name	Pin No.	Signal name
<div><div>20</div><div>18</div><div>16</div><div>14</div><div>12</div><div>10</div><div>8</div><div>6</div><div>4</div><div>2</div></div> <div><div>19</div><div>17</div><div>15</div><div>13</div><div>11</div><div>9</div><div>7</div><div>5</div><div>3</div><div>1</div></div>	CON1-20	X0	CON1-19	X8	
	CON1-18	X1	CON1-17	X9	
	CON1-16	X2	CON1-15	XA	
	CON1-14	X3	CON1-13	XB	
	CON1-12	X4	CON1-11	XC	
	CON1-10	X5	CON1-9	XD	
	CON1-8	X6	CON1-7	XE	
	CON1-6	X7	CON1-5	XF	
	CON1-4	+24V*1	CON1-3	+24V*1	
	CON1-2	24G*1	CON1-1	24G*1	

Connector for CC-Link/LT interface	Pin No.	Signal name
	1	+24V
	2	DA
	3	DB
	4	24G


No.	Item	Description																							
1)	Operating status indicator LEDs	LED name																							
		Confirmation details																							
		PW																							
		L RUN																							
		L ERR.																							
	0 to F																								
2)	Response time setting switch *2 (SW8)	Set the response time (OFF→ON/ON→OFF time) of the remote I/O module. OFF is set as default (factory-set). Noise may be taken in as input, if high speed response type is set. Be sure to set response time in consideration of the environment. ON: 0.5ms (High speed response type) OFF: 1.5ms (Standard type)																							
3)	Station number setting switches *2 (SW1 to 7)	Select "10", "20" or "40" to set the tens place of the station number. Select "1", "2", "4" or "8" to set the ones place of the station number. All switches are set to OFF at factory default setting. Always set the station number within the range of 1 to 64. A setting error occurs and "L ERR." LED flickers if the value outside the range 1 to 64 is set. (Example) Set the switches as below when setting the station number to 32:																							
		<table><tr><td rowspan="2">Station number</td><td colspan="3">Tens place</td><td colspan="4">Ones place</td></tr><tr><td>40 (SW1)</td><td>20 (SW2)</td><td>10 (SW3)</td><td>8 (SW4)</td><td>4 (SW5)</td><td>2 (SW6)</td><td>1 (SW7)</td></tr><tr><td>32</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td></tr></table>	Station number	Tens place			Ones place				40 (SW1)	20 (SW2)	10 (SW3)	8 (SW4)	4 (SW5)	2 (SW6)	1 (SW7)	32	OFF	ON	ON	OFF	OFF	ON	OFF
Station number	Tens place			Ones place																					
	40 (SW1)	20 (SW2)	10 (SW3)	8 (SW4)	4 (SW5)	2 (SW6)	1 (SW7)																		
32	OFF	ON	ON	OFF	OFF	ON	OFF																		
4)	Connector for CC-Link/LT interface	Connector for CC-Link/LT communication line, module power supply and external power supply of the input part.																							
5)	Connector for I/O interface	MIL connector for connecting input signals.																							
6)	Hook for DIN rail	Hook for installing the module on a DIN rail.																							

*1: Do not supply power to the power supply pin from the outside.
*2: Set up using a slotted screwdriver with a tip width of 0.9 mm or less.

4. Handling Precautions


- When using a DIN rail, attach the DIN rail after taking the following items into consideration:
 - Applicable DIN rail types (conform to JIS C 2812) TH35-7.5Fe TH35-7.5Ai
 - Interval between the DIN rail's installation screws Tighten the screws using a pitch of 200mm (7.87in.) or less when attaching a DIN rail.
- To attach the remote I/O module to the DIN rail, press the centerline area of the DIN rail hook beneath the module until a click is heard.
- When installing the remote I/O module into a panel, etc., provide 15mm (0.59 in.) or more of space between the top and bottom of the module and other structures or parts so that good ventilation and ease of operation when exchanging modules can be secured.

5. Wiring



*1: Do not supply power to the power supply pin from the outside.

6. External Dimensions



Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A. Tel : +1-847-478-2100	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paradiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	China	(Shanghai) Ltd. 4/F Zhi Fu Plaza, No.80 Xin Chang Road, Shanghai 200003, China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setuoy Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499
U.K	Mitsubishi Electric Europe B.V. UK Branch Travelers Lane, Hatfield, Hertfordshire., AL10 8XB, U.K. Tel : +44-1707-276100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gyang-dong, Gangseo-ku Seoul 157-200, Korea Tel : +82-2-3860-9592
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, I-20041 Agrate Brianza,, Milano, Italy Tel : +39-039-60531	Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road #05-01/02, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2-517-1326
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Ultra No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045, Jakarta, 11050 Indonesia Tel : +62-21-6630833
South Africa	Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-928-2000	India	Messung Systems Pvt. Ltd. Electronic Sadan NO.III Unit No15, M.I.D.C Brossari, Pune-411026, India Tel : +91-20-2712-3130
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-3 MARUNOUCHI, CHYODOKU, TOKYO 100-8580, JAPAN

NAGOYA WORKS : 1-14, YATAI BIRARI 5 CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.
Printed in Japan on recycled paper.